

In association with

St John
Ambulance





kinetik
WELLBEING

- Quick Start Guide -

JPD-500E

Finger Pulse
Oximeter

1



Open battery cover,
insert batteries
and replace cover.

2



Warm your hands.
Remove nail polish
and false nails
if necessary.

3



Rest for 5 minutes
before taking
your measurement.

4



Insert finger
into device.

5



Press button to take measurement. Readings can take up to 1 minute to stabilise.



for more information visit :
kinetikwellbeing.com